MBP18 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.

1 Setting up your digital baby monitor

A *Connecting power supply for the Baby unit*



- Connect the small plug of the power adapter to the baby unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC / 500mA).

B *Installing the battery pack for the Parent unit*



- Insert the wire tab of the rechargeable battery pack into the contact slot as shown above and fit the battery pack into the compartment.

C *Fastening the cover for the Parent unit*



Small cross head or Flat end screw driver.

D *Connecting power supply for the Parent unit*



- Connect the small plug of the power adapter to the parent unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC / 500mA).

WARNING:

STRANGULATION HAZARD - Keep the unit and adapter cord more than 3 feet from the crib and out of baby's reach.

NEVER place camera or cords within the crib. Secure the cord more than 3 feet away from baby's reach.

Never use extension cords with AC Adapters. Only use the AC Adapters provided.

2 Basic operation of the keys

Parent unit		
	ON/OFF button	Press and hold to turn the unit ON/OFF.
	UP/VOL+ buttons	Press to increase sound volume. Press to adjust menu up setting. Press to scroll up in 2X zoom level.
	DOWN/VOL- buttons	Press to decrease sound volume. Press to adjust menu down setting. Press to scroll down in 2X zoom level.
	MENU/OK button	Press to open menu options or exit. Press to confirm a selection. Press to pan right in 2x zoom level.
	Return/Switch Camera button	Press to return to previous menu level. Press to switch camera units. (if paired with more than one camera) Press to pan left in 2x zoom mode.
	VIDEO button	Press to turn the LCD display ON/OFF.
	ZOOM button	Press once to switch to 2x zoom level. Toggle again to return to normal view (1x).
Baby unit		
ON/OFF switch		Slide the power switch down to switch on the unit. Slide the power switch up to switch off the unit.

3 General Information

If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Visit our website: www.motorola.com
3. Contact Customer Service:

   US and Canada 1-888-331-3383

MOTOROLA

Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2013 Motorola Mobility LLC. All rights reserved.

Printed in China
Version 3.0